



## User Manual - Evaluation Boards

2011



# User Manual - Evaluation Boards

Metanoia Communications Inc. reserves the right to make changes to improve reliability or manufacturability without notice, and advise customers to obtain the latest version of relevant information to verify before placing orders. This document is commercially confidential and must NOT be disclosed to third parties without consent.

**User Manual Content**

1	Board pictures .....	2
2	Settings .....	3
2.1	EVB2301-B: LED and DIP-switch explanations .....	3
2.2	EVB2311-B: LED and DIP-switch explanations .....	4
2.3	EVB2301-BA: LED and DIP-switch explanations.....	5
2.4	EVB2301-W-RL: LED and DIP-switch explanations.....	6
3	Installation .....	7
3.1	Eyebox USB controller installation .....	8
3.2	Eyebox DIP switch settings .....	9
3.3	Eyebox Driver installation.....	9
4	DSLmonitor.....	10
4.1	Get Started .....	10
4.2	Important parameters.....	14
5	EVB2301-BA commands .....	16
5.1	System console: .....	16
5.2	Command Syntax: help or ? .....	16
5.3	Command Syntax: xdsl show .....	17
5.4	Command Syntax: xdsl profile [n].....	18
5.5	Example.....	19
6	EVB2301-W-RL Web Information.....	20
7	Using Firmware manager .....	21
7.1	EVB2301_W_RL Firmware upgrade .....	22
8	Remote Debug Support by VNC.....	23

## 1 Board pictures




Figure1: EVB2301-B



Figure2: EVB2311-B



Figure3: EVB2301-BA



Figure4: EVB2301-W-RL

## 2 Settings

### 2.1 EVB2301-B: LED and DIP-switch explanations

Step by step:

#### 1. Plug in power

Power supply: recommend for 9V/1.2A; 9V~16V/1.2A is also acceptable



Figure 1 DC Jack Polarity


#### 2. Select right (or default) profile

DIP1 (side)	DIP2-DIP3 (profile)	DIP4 (Target SNR)	DIP5
Off: CO On: CPE	Off-Off: AnnexA-30a (default) On-Off: AnnexA-17a Off-On: AnnexB-30a-997 On-On: AnnexB-17a-997	Off: 9dB (default) On: 6dB	Reserved
D2P 2,3,4 are used only at CO, and CPE follows CO's setting			

#### 3. Connect phone line to CO

#### 4. LED indicator:

LED for RJ-45			
D8	D7	D6	D5
			
Port3 port2 port1 port0		LINK/ACT	Fast : Transmitting Hold : Active

LED for RJ-11			
Power LED			
Mode LED		Power ON	Power OFF
VDSL LED		CPE mode	CO mode
		Slow : Idle Fast : Training Hold : Show time	Off line

## 2.2 EVB2311-B: LED and DIP-switch explanations

Step by step:

### 1. Plug in power

Power supply: recommend for 9V/1.2A; 9V~16V/1.2A is also acceptable



Figure 2 DC Jack Polarity

### 2. Select right (or default) profile

DIP1 (side)	DIP2-DIP3 (profile)	DIP4 (Target SNR)	DIP5
Off: CO On: CPE	Off-Off: AnnexA-30a(default) On-Off: AnnexA-17a Off-On: AnnexB-30a-997 On-On: AnnexB-17a-997	Off: 9dB(default) On: 6dB	Reserved
D2P 2,3,4 are used only at CO, and CPE follows CO's setting			

### 3. Connect phone line to CO

### 4. LED indicator:

LED for RJ-45												
LINK/ACT			Fast : Transmitting Hold : Active									
Port	Port 1			Port 2			Port 3			Port 4		
Functional ity	1GB	100M	10MB	1GB	100M	10MB	1GB	100M	10MB	1GB	100M	10MB
LED number	D1	D2	D3	D4	D5	D6	D7	D8	D9	D10	D11	D12


LED for RJ-11			
Function	LED	Power	Mode
Power	D16	Power ON	Power OFF
Mode	D17	CPE mode	CO mode
VDSL status	D18	Slow blinking : Idle Fast blinking: Training Hold : Show time	Offline

## 2.3 EVB2301-BA: LED and DIP-switch explanations

Step by step:

### 1. Plug in power

Power supply: recommend for 12V/1A



### 2. Select right (or default) profile

DIPI (mode)	DIP2-DIP3	DIP4 (Target SNR)
Off: vdsl2 normal mode On: 8051 program mode	Reserved	Off: CPE On: CO

### 3. Connect phone line to CO

### 4. LED indicator:

LED for RJ-45				
LED2	LED3	LED4	LED5	
				Port1    port2    port3    port4
	LINK/ACT		Fast : Transmitting Hold : Active	

LED for RJ-11			
LED 1			Power ON
LED 13			CO mode
LED 10			Slow : Idle Fast : Training Hold : Show time
			Power OFF
			CPE mode
			Offline

## 2.4 EVB2301-W-RL: LED and DIP-switch explanations

Step by step:

### 1. Plug in power

Power supply: recommend for 12V/1.2A



### 2. Connect phone line to CO

### 3. LED indicator:

LED for RJ-45			
LED3	LED4	LED5	LED6
Port1	port2	port3	port4
	LINK/ACT		Fast : Transmitting Hold : Active

LED for RJ-11			
LED 12			
LED 8		Power ON Slow : Idle Fast : Training Hold : Show time	Power OFF Offline

### 3 Installation

Please check the contents before installation. You'll receive one of them because of different types, as below:

One of the 4 types:

EVB2301-B

EVB2311-B

EVB2301-BA

EVB2301-W-RL

Eyebox USB controller \*1 (Figure 3)





Figure 3 Eyebox USB Controller

### 3.1 Eyebox USB controller installation



Connect USB controller to PC and reference board as Figure 6~Figure 8, make sure the cable direction is correct. If the direction is not correct, utility will not work.



Figure 6: EVB2301-B




Figure 7: EVB2311-B




Figure 8: EVB2301-BA




Figure 9: EVB2301-W-RL

\*Please match the USB controller in the PIN1(10-pin header), especially notice the red line.

### 3.2 Eyebox DIP switch settings

Mode	DIP1-DIP2	DIP3 – DIP5 (Target SNR)
Monitoring (USE THIS)	ON	OFF




Figure 4 Eyebox Tool

### 3.3 Eyebox Driver installation

When PC is connected to USB controller, driver installation is requirement. Please visit <http://www.ftdichip.com/Drivers/D2XX.htm> and select the appropriate driver for your OS.

## 4 DSLmonitor

In order to be able to monitor the status of the DSL connection on Metanoia's evaluation boards Metanoia provide the software DSLmonitor. DSLmonitor can be used to monitor most of the important parameters to enable evaluation of the connection.

### 4.1 Get Started

#### A. Start DSLmonitor

Start DSLmonitor from your *C:\DslMonitor\_for\_Merlin1.2.1\* -directory (IMPORTANT)

If Windows Vista or Windows 7 is used the DSLmonitor should be run in *Windows XP compatibility mode*.

The provided *VDSL2.drv* file must be placed in the DSLmonitor directory before running DSLmonitor.

### B. Follow the instruction of Figure 10 to start monitor modem status

1. Click the *Connect* button and when connected the button will show *disConnect*.
2. Click the *MemoryMonitor* tab.
3. Click the “...” to select the right \*.ic file.

NOTE:

- I. Choose the \*.ic file with name that matches your board's name.
- II. If your board is used in CO setting the \*.ic file ending with ...\_ot.ic should be used and ...\_rt.ic should be used if in CPE mode.
- III. The absolute (complete) file path must be given for the \*.ic file.
- IV. If the correct \*.ic file is not found in the DSLmonitor directory it should be copied into the DSLmonitor directory before used.

4. Choose “METANOIA” group
5. Click the “>>” button to move all variables in the Metanoia group to be monitored. The window to the right shows the parameters in each group and the window to the right shows the currently selected variables to monitor.

6. Click the “*Monitor Variables*” button to start monitor variables.




Figure 5 Dsl Monitor Setting Process

### C. Real-time monitoring of the variables selected in B.




Figure 6 DSL Monitor

### D. MIB variables

Most of the variables found in DSLmonitor is defined by the VDSL2 MIB standard, please take reference to the website or the provided doc file (Definitions of Managed Objects for VDSL.doc).

➤ <http://tools.ietf.org/html/rfc5650>

Here is an example of a MIB parameter:

- ✓ Upstream: xdsI2ChStatusActDataRate0
- ✓ Downstream: xdsI2ChStatusActDataRate2
- ✓

<b>TYPE</b>	Unsigned32
<b>UNIT</b>	KBits/second
<b>MAX-ACCESS</b>	Read-only
<b>STATUS</b>	Current
<b>DESCRIPTION</b>	The actual net data rate that the bearer channel is operating at, if in L0 power management state. In L1 or L2 states, it relates to the previous L0 state. The data rate is coded in bit/s
<b>REFERENCE</b>	ITU-T G.997.1, paragraph #7.5.2.1(Actual data rate)
<b>DEFVAL</b>	{ 0 }:= { xdsI2ChannelStatusEntry 2 }

## E. Discrete monitoring of MIB group variables

1. Please click the "MIB" in the top menu
2. Choose the "ChannelStatusT" MIB group tab
3. Monitor the MIP parameter value in the *ChannelStatusT* MIB group at a certain time index.




Figure 7 MIB

\*The parameter information in the above table can be found on the MIB website or in the provided file MIB.txt.

➤ <http://tools.ietf.org/html/rfc5650>

## Important parameters

In table 1 below the most commonly monitored parameters are displayed together with their MIB group and MIB name. The MIB names and grouping are originating from the working document (*Definitions of Managed Objects for Very High Speed Digital Subscriber*) by the Internet Engineering Task Force (IETF). In addition to IETF's parameters Metanoia has added a few parameters found in the Metanoia MIB group. In the document by IETF the parameters are described in more detail and also more parameters are described.

The MIB parameters are selected by the same method as in section 4.1.B for monitoring but with exception instead of *View group* the *MIB group* with the right name should be selected, as described in picture 9. The MIB parameters included in the selected MIB group are displayed in the left window and selected the desire MIB parameter and press > the parameter is added to the list of monitored variables showed in the middle of picture 9.




Figure 9 Choosing MIB parameters


Parameter	MIB group	MIB name	Unit	Coding
<b>Actual data rate US</b>	Xdsl2ChannelStatusEntry	xdsl2ChStatusActDataRate0	kbps	Usign32
<b>Actual data rate DS</b>	Xdsl2ChannelStatusEntry	xdsl2ChStatusActDataRate2	kbps	Usign32
<b>Max attainable data rate US</b>	xdsl2LineGroup	xdsl2LineStatusAttainableRateUs	kbps	Usign32
<b>Max attainable data rate DS</b>	xdsl2LineGroup	xdsl2LineStatusAttainableRateDs	kbps	Usign32
<b>Data rate before last data rate change on US</b>	xdsl2ChannelStat usGroup	xdsl2ChStatusPrevDataRate0	kbps	Usign32
<b>Data rate before last data rate change on DS</b>	xdsl2ChannelStat usGroup	xdsl2ChStatusPrevDataRate2	kbps	Usign32
<b>Target SNR margin DS</b>	Xdsl2LineConf ProfEntry	xdsl2LConfProfTargetSnrMds	0.1dB	Usign32
<b>Target SNR margin US</b>	Xdsl2LineConf ProfEntry	xdsl2LConfProfTargetSnrMus	0.1dB	Usign32
<b>Current SNR US0-4</b>	Xdsl2LineBand Entry	xdsl2LineBandStatusSnrMargin0-4	0.1dB	Int32
<b>Current SNR DS1-4</b>	Xdsl2LineBand Entry	xdsl2LineBandStatusSnrMargin5-8	0.1dB	Int32
<b>Current SNR US</b>	Xdsl2LineBand Entry	xdsl2LineBandStatusSnrMargin9	0.1dB	Int32
<b>Current SNR DS</b>	Xdsl2LineBand Entry	xdsl2LineBandStatusSnrMargin10	0.1dB	Int32
<b>Signal Attenuation</b>	Xdsl2LineBand Entry	xdsl2LineBandStatusSigAtten	0.1dB	Usign32
<b>Line Attenuation</b>	Xdsl2LineBand Entry	xdsl2LineBandStatusLnAtten	0.1dB	Usign32
<b>Actual INP US</b>	Xdsl2ChannelStatusEntry	xdsl2ChStatusActInp0	0.1 symbols	Usign32
<b>Actual INP DS</b>	Xdsl2ChannelStatusEntry	xdsl2ChStatusActInp2	0.1 symbols	Usign32
<b>Actual delay US</b>	Xdsl2ChannelStatusEntry	xdsl2ChStatusActDelay0	ms	Usign32
<b>Actual delay DS</b>	Xdsl2ChannelStatusEntry	xdsl2ChStatusActDelay2	ms	Usign32
<b>CRC error counter US</b>	Metanoia	xdslMetanoiaOtCodingViolations0		Usign32
<b>CRC error counter DS</b>	Metanoia	xdslMetanoiaRtCodingViolations0		Usign32
<b>FEC corrected blocks US</b>	Metanoia	xdslMetanoiaOtCorrectedBlocks0		Usign32
<b>FEC corrected blocks DS</b>	Metanoia	xdslMetanoiaRtCorrectedBlocks0		Usign32

Table 1: Important (MIB) parameters.

## 5 EVB2301-BA commands

### 5.1 System console:

Connect a serial port to RS232 and set the baud rate to 38400 N81 and the password : **admin**



```
Press any key to bypass loading Firmware and Settings...
=====
Metanoia (R) Prestige xDSL-OT Modem Version 1.1.0.9.8.17
=====

System initializing...

xDSL Firmware Version: 1.1.0 (06/22/2009 17:51:18 build)
Reset xDSL Chip 1...
Download Merlin firmware (168207 bytes) to DSP chip ... done


Password: ****

xDSL>
```

Figure 8 Log In Setting

### 5.2 Command Syntax: help or ?

**Description:** Display all of commands supported in this unit. A typical outcome is shown as below:




```
xDSL>help
help or ?
exit
password
factory
upgrade [fw]
xDSL reset
xDSL show
xDSL show-pm
xDSL profile [n]
xDSL target-us-snrr [n]
xDSL target-ds-snrr [n]
xDSL max-us-datarate [n]
xDSL max-ds-datarate [n]
xDSL min-us-datarate [n]
xDSL min-ds-datarate [n]
xDSL max-us-delay [n]
xDSL max-ds-delay [n]
xDSL min-us-inp [n]
xDSL min-ds-inp [n]
xDSL ghscarrierset [n]
xDSL debug [n]
xDSL getmib [g t p i]
xDSL setmib [g t p i v]
xDSL setmib-s [g t p i v]
xDSL read-mem [s][h]
xDSL write-mem [s][h][h]
xDSL mib-dump [h]
xDSL flash-dump [h]
net read [phy][reg]
net write [phy][reg][n]
xDSL>
xDSL>
```

- print CLI command help  
- exit CLI  
- change CLI login password  
- reset all settings to factory default  
- firmware upgrade  
- reset xDSL chip  
- print xDSL status  
- print xDSL Line and Channel Performance Monitoring status  
- change/print xDSL profile  
- change/print xDSL US Target SNR margin(30 - 240 0.1dB)  
- change/print xDSL DS Target SNR margin(30 - 240 0.1dB)  
- change/print xDSL US Max datarate(256 - 101064 kb)  
- change/print xDSL DS Max datarate(256 - 101064 kb)  
- change/print xDSL US Min datarate(256 - 100000 kb)  
- change/print xDSL DS Min datarate(256 - 100000 kb)  
- change/print xDSL US Max delay down (0 - 255 ms)  
- change/print xDSL DS Max delay down (0 - 255 ms)  
- change/print xDSL US Min INP (1 - 18)  
- change/print xDSL DS Min INP (1 - 18)  
- change/print xDSL GhsCarrierSet (0,1,2,7)  
- change/print xDSL GhsCarrierSet (0 - 10)  
- Get xDSL MIB (group[n] table[n] param[n] index[n])  
- Set xDSL MIB (group[n] table[n] param[n] index[n] value[n])  
- Set and save xDSL MIB (group[n] table[n] param[n] index[n] value[n])  
- Read xDSL MIB (type[x|y] address[hex])  
- Write xDSL MIB (type[x|y] address[hex] value[hex])  
- dump 192-bytes from the specified MIB address (address[hex])  
- dump 128-bytes from the specified flash address (address[hex])  
- net read  
- net write

Figure 9 Command 1

### 5.3 Command Syntax: xDSL show

**Description:** this is very useful command used to check current xDSL interface status, including firmware version, status, upstream/downstream actual data rate, SNR, INP values, etc.



```

COM1_38400 - SecureCRT
File Edit View Options Transfer Script Tools Help
File Explorer Task List Search Task List Help
COM1_38400
xDSL>
xDSL>
xDSL>xDSL show

xDSL System Ver 1.1.0.9.8.17
xDSL Firmware Version 1.1.0 (06/22/2009 17:51:18 build)

xDSL CO
xDSL Profile: 30a
xDSL Band Profile AnnexA_R_POTS_D-32_EU-32_30a
xDSL link status: Showtime

xDSL Port Details          Upstream / Downstream (Unit)
=====
Attainable data rate      118391 / 191437 (Kbps)
Actual data rate          101057 / 101054 (Kbps)
Prev data rate             56902 / 101059 (Kbps)
Actual Delay               3 / 0 (ms)
Actual INP                 20 / 0 (0.1symbol)
SNR Margin                 63 / 243 (0.1db)
Signal Attenuation          0 / 0 (0.1db)
Line Attenuation            0 / 0 (0.1db)
Transmit Power              140 / 144 (0.1dbm)
Trellis                      true / true
Interleaving Depth          502 / 1
Interleaving Block           81 / 255

xDSL Band Status          U0   U1   U2   U3   U4   D1   D2   D3   D4   (Unit)
=====
SNR Margin                 0    76   61   62   0    244  248  241  0    (0.1db)
Signal Attenuation          0    0    0    0    0    0    0    0    0    (0.1db)
Line Attenuation            0    0    0    0    0    0    0    0    0    (0.1db)

xDSL Channel Profile Setup Upstream / Downstream (Unit)
=====
Max data rate                101064 / 101064 (Kbps)
Min data rate                 256 / 256 (Kbps)
Target SNR                   60 / 60 (0.1db)
Max interleave                8 / 8 (ms)
Min INP                      NO_PROTECTION / NO_PROTECTION


xDSL>

```

Figure 10 Command 2

## 5.4 Command Syntax: xDSL profile [n]

**Description:** this command is only valid when device is configured in COT mode. Without parameter [n], this command will display how many profiles supported in device and current selected profile. With [n] parameter, the device will switch its profile to selected one. For profile definition, please refer to ITU-T G.993.2 Recommendation or contact technical support. Please be noted, the different COT firmware might support different set of xDSL profiles.



```

COM1_38400 - SecureCRT
File Edit View Options Transfer Script Tools Help
File Explorer Task List Search Print Properties Find Replace Help
COM1_38400
xDSL>xDSL profile

Number: 1 (AnnexA_R_POTS_D-32_EU-32_30a)
2 (AnnexA_R_POTS_D-32_EU-32_17a)
3 (AnnexA_R_POTS_D-32_EU-32_12b)
4 (AnnexA_R_POTS_D-32_EU-32_12a)
5 (AnnexA_R_POTS_D-32_EU-32_8a)
6 (AnnexA_R_POTS_D-32_EU-32_8b)
7 (AnnexA_R_POTS_D-32_EU-32_8c)
8 (AnnexA_R_POTS_D-32_EU-32_8d)
9 (AnnexA_R_POTS_D-64_EU-64_30a)
10 (AnnexA_R_POTS_D-64_EU-64_17a)
11 (AnnexB_997_997-M1c-A7)
12 (AnnexB_997_997-M1x-M-8)
13 (AnnexB_997_997-M1x-M)
14 (AnnexB_997_997-M2x-M-8)
15 (AnnexB_997_997-M2x-A)
16 (AnnexB_997_997-M2x-M)
17 (AnnexB_997_997E17-M2x-A)
18 (AnnexB_997_997E30-M2x-NUS0)
19 (AnnexB_998_998-M1x-A)
20 (AnnexB_998_998-M1x-B)
21 (AnnexB_998_998-M1x-NUS0)
22 (AnnexB_998_998-M2x-A)
23 (AnnexB_998_998-M2x-M)
24 (AnnexB_998_998-M2x-B)
25 (AnnexB_998_998-M2x-NUS0)
26 (AnnexB_998_998E17-M2x-NUS0)
27 (AnnexB_998_998E17-M2x-NUS0-M)
28 (AnnexB_998_998ADE17-M2x-NUS0-M)
29 (AnnexB_998_998ADE17-M2x-A)
30 (AnnexB_998_998ADE17-M2x-B)
31 (AnnexB_998_998E30-M2x-NUS0)
32 (AnnexB_998_998E30-M2x-NUS0-M)
33 (AnnexB_998_998ADE30-M2x-NUS0-M)
34 (AnnexB_998_998ADE30-M2x-NUS0-A)
35 (AnnexC_POTS_25-138_b)
36 (AnnexC_POTS_25-276_b)
37 (AnnexC_TCM-ISDN)


xDSL Port 1 Actual profile: 2 (AnnexA_R_POTS_D-32_EU-32_17a)
xDSL>

```

Figure 11 Command 3

## 5.5 Example

admin> xdsl profile 2




```
xDSL>
xDSL>xDSL profile 2
.....
xDSL profile running...
xDSL>
```

Figure 12 Command 4

## 6 EVB2301-W-RL Web Information

How to get the VDSL status?

1. Go to the website : <http://10.10.10.254>
2. Log in (account and code are both “**admin**”)
3. Choose **VDSL Status** of Administration file
4. Then, take a look at the status of Metanoia VDSL, as Figure 19



VDSL			
Link Status	Showtime		
Firmware Version	010100		
Basic Status			
	Upstream	Downstream	Unit
Line Rate	132744	172920	Kb/s
Actual Data Rate	100055	100061	Kb/s
SNR	67	168	0.1dB
Advance Status			
	Upstream	Downstream	Unit
Actual delay	3	5	ms
Actual INP	22	70	0.1 symbols
15M CV	0	0	counter
1Day CV	0	0	counter
15M FEC	0	0	counter
1Day FEC	3852360	0	counter
Total FEC	333	0	counter
Previous Data Rate	100058	0	Kbps
Attainable Rate	119168	201440	Kbps
Electrical Length	3	3	0.1 dB
SNR Margin	N/A	N/A	(US0,~) 0.1 dB
SNR Margin	93	172	(US1,DS1) 0.1 dB
SNR Margin	65	170	(US2,DS2) 0.1 dB
SNR Margin	63	168	(US3,DS3) 0.1 dB
SNR Margin	N/A	N/A	(US4,DS4) 0.1 dB
15M Elapsed time	830	830	secs
15M FECS	0	0	counter

Figure 13 EVB2301\_W\_RL VDSL Status

## 7 Using Firmware manager

When you need to upgrade modem code, you need this tool.

- a. Make sure eyebox controller DIP setting is  
\*X4:3,4,5 switch ON and 1,2 switch OFF
- b. Run the FirmwareManager.exe in the directory.
- c. Follow the instruction of Figure 20 to flash firmware.
  1. Connect Eyebox to SPI flash.
  2. Select the location of firmware
  3. Download firmware to SPI flash
  4. Flash complete




Figure 14 Firmware Manager Process

- d. After about 1 minute, you will see "Flash complete" in the window caption.

\*X4: the latest DIP version

## 7.1 EVB2301\_W\_RL Firmware upgrade

Upgrade the firmware on the website step by step

- a. Go to the website : <http://10.10.10.254>
- b. Log in (account and code are both “**admin**”)
- c. Choose **Upload Firmware** of Administration file
- d. Find the file we provide, then click “**Apply**”, as Figure 21



Figure 15 EVB2301\_W\_RL Firmware Upgrade

## 8 Remote Debug Support by VNC

- I. When Complex problem or IOP problem that is not easy to describe.
- II. Metanoia support team will use remote desktop (VNC) to help you.
  - When to use:
  - Requirement:
    - ◆ Internet access is required
    - ◆ Windows system
  - Step by step:
    - ◆ Reference as the ***installation guide CD***
    - ◆ Path: PC\CD\_ROM\_Module\Remote Support
    - ◆ Use TeamViewerQS
    - ◆ Please provide your ID and password to us, as below.



Figure 16 TeamViewerQS Log In